

Hands Free Microphone Instructions

The headset and Lapel microphone are located in the FIFINE box in the top drawer of the sound cabinet – please use with care and return them here after use.

Decide whether you want the headset or the lapel microphone and plug whichever into the transmitter. The transmitter is worn on your belt, waste band or in jacket pocket. Turn it on so that digital display lights up and shows a frequency (don't worry about that).


Turn on the hall amplifier and mixer unit – see separate instructions (they are working if the blue light on front of Amp is on and the mixer has red/yellow lights lit up).

Turn on the receiver unit which is plugged into Channel 9 on the mixer – a red light comes on at the back of the unit – see photo.

Test required volume and adjust using slider on mixer and volume knob for channel 9 (see photo). Do not use excessive volume as it may induce howling (feedback) when in front of the hall speakers.

After use please remember to turn off both the transmitter and the receiver as these are battery operated – spare batteries are in the box (ideally) or the drawer – discard flat batteries to avoid confusion.


Any questions ring/text Robin on 07712246355/ 01452700882



Transmitter

AA Batteries

On/off switch



Receiver in mixer (Channel 9)

AAA Batteries

On/off switch
and red light

Channel 9 Volume and
main volume slide control